




Shoulder Strap T300 User's Manual



STAR MICRONICS CO., LTD.

Warning / Safety Guidelines


- Carry the printer with the shoulder strap diagonally across the chest. (As shown in the illustration.)



Do not put the shoulder strap around or hang the printer from the neck.


- Keep away from children.
- Do not swing the printer by the shoulder strap.

■ Shoulder Strap Parts Breakdown




■ Installing the Shoulder Strap T300 on the SM-T300

1. Pull the hooks down on the SM-T300 in the direction of the arrows.




2. Feed the left side of the strap through the hook in the order of the numbers below. Then, push at least two inches (50mm) of the loose end through the buckle to secure it.



3. Repeat Step 2 to secure the right side of the strap.
4. With both sides locked, adjust the strap length to the user's comfort. Hold the buckle and pull it in the desired direction to make it longer or shorter.

NOTE: The strap will detach if it is not fed through the buckle. Take care to leave approximately two inches (50mm) of slack so it remains secured.



ショルダーストラップ T300 User's Manual



スター精密株式会社


安全上のご注意

- ・ショルダーストラップはイラストのように、肩から斜めに掛けてください。首のまわりに巻きつけたり、首からさげて使用しないでください。



- ・ショルダーストラップはお子様手の届かない場所に保管してください。
- ・ショルダーストラップを持って、プリンタを振り回さないでください。


■ 外観と各部の名称




■ ショルダーストラップの取り付け手順

以下の手順にて、SM-T300へ取り付けてください。

1. SM-T300のフックを下図のように手前に倒してください。



2. ストラップ先端が左の場合は、プリンタ左側のフックへ、先端が右側の場合はプリンタ右側のフックへ、下図①のように通してください。その後、ストラップ先端から50mm以上余裕をもたせた位置を②～③のようにバックルに通し、ストラップの先端をリングに通してください。



注意：ストラップは、フックを通した後、バックルへ通さないで外れてしまいます。しっかりと固定するために位置はストラップ先端から50mm以上余裕を持たせてください。

3. もう一方のストラップ先端を手順2に従って、固定してください。
4. ストラップの両端をしっかりと固定した後、バックルを持ち、ストラップを先端の方向、または先端とは逆の方向へ引っ張りながら長さを決めてください。