




HOW TO INSTALL TCP300II/TCP400 PRINTER DRIVER IN WIN 7/VISTA 64 BIT

1. Download TCP300II/TCP400 CD at http://www.starasia.com.hk/dl/cd/TCP300II_400_CD_10102011.zip and run "setup" after extracting the zip file



STAR-ASIA TECHNOLOGY LTD.


Tel: (852)2799-6682 Fax: (852)2798-5050

Url : <http://www.starasia.com>


Email: info@starasia.com



2. Starting the installation



3. Press "Next"



STAR-ASIA TECHNOLOGY LTD.


Tel: (852)2799-6682 Fax: (852)2798-5050

Url : <http://www.starasia.com>


Email: info@starasia.com



4. Input the requested information and press “Next”



5. Press “Install”



STAR-ASIA TECHNOLOGY LTD.

Tel: (852)2799-6682 Fax: (852)2798-5050

Url : <http://www.starasia.com>


Email: info@starasia.com



6. Installing



7. Press "Finish" to complete InstallShield Wizard



STAR-ASIA TECHNOLOGY LTD.


Tel: (852)2799-6682 Fax: (852)2798-5050

Url : <http://www.starasia.com>

Email: info@starasia.com



8. Discontinue the installation



STAR-ASIA TECHNOLOGY LTD.


Tel: (852)2799-6682 Fax: (852)2798-5050

Url : <http://www.starasia.com>

Email: info@starasia.com



9. Check the assigned virtual port number in Device Manager. (Printer must connect to PC and the power should be ON)



STAR-ASIA TECHNOLOGY LTD.

Tel: (852)2799-6682 Fax: (852)2798-5050

Url : <http://www.starasia.com>

Email: info@starasia.com



10. Add printer manually



STAR-ASIA TECHNOLOGY LTD.

Tel: (852)2799-6682 Fax: (852)2798-5050

Url : <http://www.starasia.com>

Email: info@starasia.com



11. Add local printer



STAR-ASIA TECHNOLOGY LTD.

Tel: (852)2799-6682 Fax: (852)2798-5050

Url : <http://www.starasia.com>

Email: info@starasia.com



12. Selecting the virtual port number found in Step 9 and press “Next”



STAR-ASIA TECHNOLOGY LTD.

Tel: (852)2799-6682 Fax: (852)2798-5050

Url : <http://www.starasia.com>

Email: info@starasia.com



13. Select the manufacturer and model name.

(For new installation, please select "Have disk" and select the path. Goto Step 15)



STAR-ASIA TECHNOLOGY LTD.


Tel: (852)2799-6682 Fax: (852)2798-5050

Url : <http://www.starasia.com>

Email: info@starasia.com



14 Press "Next"



STAR-ASIA TECHNOLOGY LTD.

Tel: (852)2799-6682 Fax: (852)2798-5050

Url : <http://www.starasia.com>

Email: info@starasia.com



15. Input Printer Name and press "Next"



STAR-ASIA TECHNOLOGY LTD.

Tel: (852)2799-6682 Fax: (852)2798-5050

Url : <http://www.starasia.com>

Email: info@starasia.com



16. Press "Complete"



STAR-ASIA TECHNOLOGY LTD.

Tel: (852)2799-6682 Fax: (852)2798-5050

Url : <http://www.starasia.com>

Email: info@starasia.com



17. New print queue is created



STAR-ASIA TECHNOLOGY LTD.

Tel: (852)2799-6682 Fax: (852)2798-5050


Url : <http://www.starasia.com>

Email: info@starasia.com




For Developer only

1. VB 2008 sample project can be provided on request. Please fill in the enquiry form at <http://www.starasia.com/enquiry.asp>
2. Select "Tools" -> "Option"



3. Click "Show advanced options"



STAR-ASIA TECHNOLOGY LTD.


Tel: (852)2799-6682 Fax: (852)2798-5050

Url : <http://www.starasia.com>


Email: info@starasia.com



4. Select "Build" -> "Config Manger"



5. Change the CPU Type



STAR-ASIA TECHNOLOGY LTD.


Tel: (852)2799-6682 Fax: (852)2798-5050

Url : <http://www.starasia.com>

Email: info@starasia.com



6. Select X86 CPU



7. Finished.

TCP300II/TCP400 can print/erase the card & read/write the magnetic stripe in Win7/Vista 64 now!

STAR-ASIA TECHNOLOGY LTD.

Tel: (852)2799-6682 Fax: (852)2798-5050

Url : <http://www.starasia.com>

Email: info@starasia.com